



Filter Cleaner and Degreaser

Dose rates - see below



What is it?

Lo-Chlor Filter Cleaner and Degreaser is a superior formulated swimming pool filter cleaner.

Who needs it?

- Every pool owner to periodically clean their filter.

What does it do?

- Filter Cleaner and Degreaser is designed to clean and degrease filters.

What advantages does it have over other similar products?

- Filter Cleaner and Degreaser uses an advanced formulation for the cleaning and degreasing of DE filters and cartridge filter grids.
- It may be used for all types of sand filters.
- Removes grime, dead algae, oil, organic deposits as well as scale and unwanted metals.

Professional tips:

- Never add Filter Cleaner and Degreaser to the pool water.
- For cartridge filters and DE, best results will be obtained when the soiled elements are hosed, to remove as much debris as possible, before using Filter Cleaner and Degreaser.
- Also hose well before re-assembly after having used Filter Cleaner and Degreaser.
- We recommended that sand filters be cleaned at least once a year.
- We recommend that cartridge and DE filters be cleaned as necessary.
- When closing a pool down for winter it is also recommended that the filter is cleaned as part of the shutdown program.

Dose Rates: Cartridge and DE Filter add 1 litre to 50 litres of cold water in a suitable clean plastic container.

Sand Filters add 1 litre to 10 litres of cold water in a suitable clean plastic container.